

Gefeliciteerd!

Beste bewoner,

Van harte gefeliciteerd met uw duurzame woning!
We helpen u graag op weg met het instellen van uw systeem voor verwarmen, koelen en warm water. In deze video* kunt u zien hoe het systeem werkt:

Scan mij



Of ga naar YouTube.com

Zoek ons kanaal

Zoek op de titel **Bewonersuitleg klimaatstelsel**

*Let op! Dit is een algemene video; mogelijk is in uw woning andere apparatuur geplaatst.

De temperatuur instellen

U hoeft de thermostaat maar één keer in te stellen op het gewenste comfortniveau. Hierna verloopt verwarmen en koelen volledig automatisch. De warmtepomp werkt het zuinigst wanneer de temperatuurinstelling constant blijft. De verwarming werkt met een lage temperatuur via de vloer en dat zorgt voor een stabiele binnentemperatuur. Veranderingen in de temperatuur gaan langzaam, met ongeveer 1°C per 24 uur. Opwarmen en afkoelen gebeurt dus heel geleidelijk en comfortabel! Daarom is het slim om de thermostaat ook 's nachts op dezelfde temperatuur te laten staan. Zelfs als u op vakantie gaat, is dit het zuinigst. Gaat u langer dan 2 maanden weg, dan kunt u de thermostaat instellen op 20°C.



BELANGRIJK

- Houd de ingestelde temperatuur zoveel mogelijk constant
- Laat de warmtepomp altijd aan staan, ook bij afwezigheid.
- De vloer zal niet warm aanvoelen, dit is normaal. Als het vlammetje op uw thermostaat zichtbaar is weet u dat de warmtepomp in verwarmmodus staat.
- Kort luchten kan altijd maar laat ramen en deuren niet (te lang) open staan.
- Koeling is niet alleen comfortabel maar ook nuttig. Naast een paar graden verkoeling in de zomerperiode laadt met het koelen tegelijkertijd de bron op. Zo geeft de koelfunctie ook nog energiewinst voor het stookseizoen!

Warm water instellingen

De warmtepomp verzorgt ook de verwarming van het tapwater in het voorraadvat. Het warme water wordt bewaard in het voorraadvat en kan direct gebruikt worden. Bij oplevering staat de warmtepomp in de ECO-stand. In deze stand verwarmt de warmtepomp het voorraadvat eenmaal per dag. Het tijdstip hiervoor kunt u via de thermostaat instellen.

In deze video* kunt u zien hoe u uw voorkeuren kunt instellen:

Scan mij



Of ga naar YouTube.com

Zoek het kanaal

Zoek op de titel **Producten - Spider Klimaatthermostaat - Itho Daalderop**

Hebt u vragen of staat er een foutmelding op de thermostaat? Dan kunt u deze pagina raadplegen:

Scan mij



Of ga naar www.ithodaalderop.nl/bewoners

Met vriendelijke groet,

Itho Daalderop



GEBRUIKERSTIPS

- U kunt de woning even luchten door kort de ramen open te zetten. Maar houd in koudere periodes de kou zoveel mogelijk buiten door ramen niet (te lang) open te laten. Uw ventilatiesysteem zorgt continu voor verse lucht.
- U kunt het tijdstip van opwarmen van het voorraadvat zelf aanpassen.
- Indien u de ECO-stand aanpast naar de BOOST-stand zal het voorraadvat het tapwater eenmalig verwarmen. Het duurt enkele uren om het voorraadvat geheel op te warmen.
- Voor meer comfort kunt u de COMFORT-stand voor warm water kiezen. Het tapwater wordt in deze stand opgewarmd zodra de watertemperatuur onder de 45 °C daalt. Het duurt enkele uren om het voorraadvat geheel op te warmen.
- Voor extra warm water comfort kunt u in de keuken een boiler gebruiken.

Congratulations!

Dear resident,

Congratulations on your new sustainable home! We would love to help you to set up your system for heating, cooling and hot water. This video* explains how your system works.

Scan me



Or visit  YouTube.com

Search our channel  itho daalderop

Search by title **Bewonersuitleg klimaatsysteem**

*Please note!: This is a general video; different equipment may be installed in your home.

Temperature settings

Set the temperature once in keeping with your desired level of comfort. Thereafter, the heating and cooling system will run fully automatically. The heat pump system will run most efficiently when the temperature setting remains constant. The heating system uses low temperature heating thanks to the underfloor heating system, which ensures a stable temperature inside your home. Changes in temperature occur slowly; approximately 1°C every 24 hours. This means the heating and cooling processes are very gradual and comfortable. That's why it is smart to also leave the thermostat on the same temperature at night. This is the most economical option, even if you go on holiday. If you are away from home for 2 or more months, you can set the thermostat to 20°C.



IMPORTANT

- Keep the temperature settings constant
- Always leave the heat pump turned on, even when you are not home
- The floor will not feel warm; this is normal. If the flame symbol on the thermostat is visible, the heat pump will be in heating mode.
- It is always possible to briefly ventilate your home but make sure you do not leave windows and doors open (for too long).
- Cooling is not only comfortable but it is also useful. Besides reducing the temperature by a few degrees in summer, cooling also recharges the well (underground heat exchanger)

Hot water settings

The heat pump also provides domestic hot water. The hot water is stored in the storage tank and can be used immediately. The heat pump will be set to ECO mode when delivered. During this mode, the storage tank is heated by the heat pump once a day. You can use the thermostat to set the heating time.

This instruction video* shows how to change the settings to match your preferences.

Scan me



Or visit  YouTube.com

Search the  itho daalderop channel

Search by title **Producten - Spider
Klimaatthermostaat - Itho Daalderop**

Do you have questions or is there an error on the thermostat display? Check out this website.

Scan me



Or go to www.ithodaalderop.nl/bewoners

Sincerely,

Itho Daalderop



TIPS AND TRICKS

- You can ventilate your home by briefly opening the windows. However, in colder periods, make sure that the cold is kept out as much as possible by not leaving the windows open (for too long). Fresh air is supplied by your ventilation system.
- You can adjust the time at which water in the storage tank is heated.
- If you switch from ECO mode to BOOST mode, the storage tank will heat the water by boosting the temperature once. An empty tank takes several hours to heat.
- For additional comfort, you can select the COMFORT mode for extra hot water. During this mode, tap water is heated as soon as the water temperature drops below 45 °C. It takes several hours for the storage tank to fully heat up.
- For extra comfort, you can use an extra boiler in the kitchen.